

## **EVALUACIÓN – PRUEBA DE HABILIDADES PRÁCTICAS CCNA**

**JOHN ASMETH BUSTOS BARRERA**

**UNAD “UNIVERSIDAD ABIERTA Y A DISTANCIA”**

**INGENIERIA ELECTRONICA**

**ESCUELA DE CIENCIAS BASICAS Y TECNOLOGIAS**

**BOGOTA D.C.**

**MAYO-2019**

## **EVALUACIÓN – PRUEBA DE HABILIDADES PRÁCTICAS CCNA**

**JOHN ASMETH BUSTOS BARRERA**

### **PRUEBA DE HABILIDADES PRACTICAS CCNA**

**INGENIERO. JUAN CARLOS VESGA FERREIRA**

**DIRECTOR DEL DIPLOMADO**

**INGENIERO. IVAN GUSTAVO PENA**

**TUTOR DE GRUPO**

**UNAD “UNIVERSIDAD ABIERTA Y A DISTANCIA”**

**INGENIERIA ELECTRONICA**

**ESCUELA DE CIENCIAS BASICAS Y TECNOLOGIAS**

**BOGOTA D.C.**

**2019**

Nota de Aceptación

---

---

---

Presidente del Jurado

---

---

Jurado

---

---

Jurado

Bogotá D.C. 23 de Mayo de 2019

## **Dedicatoria**

Dedico este trabajo a todos  
aquellos que profesionalmente  
han dejado algo edificante en mí.

## **AGRADECIMIENTOS**

Agradezco a mis maestros y compañeros de carrera, quienes profesionalmente han dejado algo edificante en mí. A mi familia y allegados por su constancia y paciencia en torno a mi formación académica

## CONTENIDO

1	INTRODUCCION .....	14
2	OBJETIVOS.....	15
2.1	OBJETIVO GENERAL .....	15
2.2	OBJETIVOS ESPECÍFICOS.....	15
3	DESCRIPCION DEL ESCENARIO 1 .....	16
3.1	DESARROLLO ESCENARIO 1 .....	20
3.1.1	CONFIGURACION DEL DIRECCIONAMIENTO.....	20
3.1.2	CONFIGURACION DEL ISP .....	20
3.1.3	CONFIGURACION MEDELLIN 1 .....	21
3.1.4	CONFIGURACION MEDELLIN 2 .....	22
3.1.5	CONFIGURACION MEDELLIN 3 .....	23
3.1.6	CONFIGURACION BOGOTA 1.....	25
3.1.7	CONFIGURACION BOGOTA 2.....	26
3.1.8	CONFIGURACION BOGOTA 3.....	27
3.2	CONFIGURACION DE RIP COMO PROTOCOLO DE ENRUTAMIENTO	
	28	
3.2.1	MEDELLIN 1 .....	28
3.2.2	MEDELLIN 2 .....	29
3.2.3	MEDELLIN 3 .....	30
3.2.4	BOGOTA 1 .....	31
3.2.5	BOGOTA 2 .....	32
3.2.6	BOGOTA 3.....	33
3.3	MOSTRANDO RUTAS Y ELEMENTOS DE LOS RUTERS BOGOTA Y	

MEDELLIN .....	34
3.4 RUTA POR DEFECTO HACIA EL ISP .....	35
3.4.1 MEDELLIN .....	35
3.4.2 BOGOTA.....	36
3.5 ROUTER ISP CON RUTA ESTÁTICA.....	37
3.6 BALANCEO DE CARGA Y VISUALIZACION DE RUTAS REDUNDANTES	
39	
3.7 CONFIGURACION ENCAPSULAMIENTO Y AUTENTICACIÓN PPP ....	39
3.7.1 ISP .....	39
3.7.2 MEDELLIN .....	40
3.8 CONFIGURACIÓN DEL SERVICIO DHCP .....	42
3.8.1 MEDELLIN .....	42
3.8.2 BOGOTA.....	43
3.9 PING ENTRE PC.....	46
3.10 CONFIGURACION PAT .....	46
3.10.1 MEDELLIN .....	46
3.10.2 BOGOTA.....	47
3.11 ASIGNACION DE CLAVES DE SEGURIDAD.....	49
3.11.1 MEDELLIN .....	49
3.11.2 BOGOTA.....	49
4 DESCRIPCION DEL ESCENARIO 2.....	49
4.1 DESARROLLO ESCENARIO 2 .....	52
4.2 CONFIGURACIÓN BASICA .....	53
4.2.1 R1.....	53
4.2.2 R2.....	53

4.2.3	R3.....	54
4.2.4	S1.....	54
4.2.5	S3.....	55
4.3	CONFIGURACION DEL DIRECCIONAMIENTO IP.....	55
4.3.1	R1.....	56
4.3.2	R2.....	57
4.3.3	R3.....	58
4.4	CONFIGURACION DE OSPFV2.....	60
4.4.1	R1.....	60
4.4.2	R2.....	61
4.4.3	R3.....	61
4.5	VISUALIZACION DE TABLAS DE ENRUTAMIENTO .....	62
4.6	VISUALIZAR LISTA RESUMIDA DE INTERFACES POR OSPF .....	65
4.7	VISUALIZACION DE ID .....	67
4.8	CONFIGURACION AVANZADA SEGÚN TOPOLOGIA .....	69
4.8.1	S1.....	69
4.8.2	S3.....	70
4.9	DIRECCIONES IP DE LOS SWITCHES.....	71
4.9.1	S1.....	71
4.9.2	S3.....	71
4.10	DEACTIVAR TODAS LAS INTERFACES .....	72
4.10.1	S1 .....	72
4.10.2	S3 .....	73
4.11	IMPLEMENTACION DE DHCP NAT .....	73
4.12	CONFIGURACION DE SERVIDOR DHCP .....	75

4.12.1	R1 .....	75
4.13	RESERVA DE DIRECCIONES IP .....	75
4.14	CONFIGURACION DE NAT .....	76
5	CONCLUSIONES .....	79
	REFERENCIAS BIBLIOGRAFÍCAS.....	80

## TABLA DE ILUSTRACIONES

Ilustración 1. Topología escenario 1 .....	16
Ilustración 2. Desarrollo de la topología escenario 1.....	20
Ilustración 3 Configuración RIP para Medellín 1 .....	28
Ilustración 4 Configuración RIP para Medellín 2 .....	29
Ilustración 5 Configuración RIP para Medellín 3 .....	30
Ilustración 6 Configuración RIP para Bogota 1 .....	31
Ilustración 7 Configuración RIP para Bogota 2 .....	32
Ilustración 8 Configuración RIP para Bogotá 3 .....	33
Ilustración 9 Ruta de Bogota 1.....	34
Ilustración 10 Ruta de Medellin 1 .....	35
Ilustración 11 Ruta por defecto Medellin 2 .....	36
Ilustración 12 Ruta por defecto Bogota 2 .....	37
Ilustración 13 Ruta estatica Bogota 2.....	38
Ilustración 14Ruta redundante Medellin 3.....	39
Ilustración 15 Encapsulamiento y autenticación PPP Medellín 1 .....	41
Ilustración 16 Verificación de las diferentes redes .....	41
Ilustración 17 Servicio DHCP PCB.....	42
Ilustración 18 servicio DHCP PC1 .....	43
Ilustración 19 Servicio DHCP PC3.....	44
Ilustración 20 Servicio DHCP PC2 .....	45
Ilustración 21 Ping en PC2.....	46
Ilustración 22 Ping PC.....	46
Ilustración 23 Ping PC1.....	48
Ilustración 24 Ping fallando en PC1 .....	48
Ilustración 25 Topología escenario 2 .....	50
Ilustración 26 Desarrollo de la topología escenario 2.....	52
Ilustración 27 Configuración IP PC .....	55

Ilustración 28 Configuración IP Servidor.....	56
Ilustración 29 Tablas de enrutamiento R1.....	62
Ilustración 30 Tablas de enrutamiento R2.....	63
Ilustración 31 Tablas de enrutamiento R3.....	64
Ilustración 32 Listas OSP R1 .....	65
Ilustración 33 Listas OSP R2 .....	66
Ilustración 34 Visualizacion ID R1.....	67
Ilustración 35 Visualizacion ID R2.....	68
Ilustración 36 Visualizacion ID R3.....	69
Ilustración 37 DHCP NAT PC-A.....	73
Ilustración 38 DHCP NAT PC-C.....	74
Ilustración 39 Configuración NAT en R1 .....	77
Ilustración 40 Configuración NAT en S1 .....	78

## **GLOSARIO**

**ANCHO DE BANDA:** Capacidad de transmisión de una red

**DIRECCIÓN IP:** Identificación determinada de una red externa o interna

**DIRECCIÓN IP DINÁMICA:** Dirección IP temporal asignada a un DHCP.

**DIRECCIÓN IP ESTÁTICA:** Dirección IP fija asignada a dispositivo

**ETHERNET:** Protocolo que especifica la forma en que se colocan los datos en un medio de transmisión común.

**GATEWAY:** Dispositivo de una red que sirve de acceso a otra

**HOSTS:** indicador en un sistema identificando red, servidores de acceso y rosters.

**RAM:** Memoria volátil de un dispositivo

**ROM:** Memoria no volátil de un dispositivo

**VLSM:** máscara de subred de longitud variable.

**PAQUETE:** información que se usa como control con los datos del usuario.

**RIP:** Protocolo de información para el conteo de saltos de enrutamiento.

**PROTOCOLO:** ruta que marca y muestra el camino de la información que ejecutara un proceso en la red.

**NVRAM:** Memoria de acceso aleatorio que guarda diferentes contenidos

**WAN:** Red de comunicación de datos que sirve a los usuarios dentro de un área geográficamente extensa

**LAN:** Red de área local instaladas en múltiples ubicaciones.

**ROUTER:** Dispositivo que envía paquetes desde una red a otra

## **RESUMEN**

En el desarrollo de este trabajo se realizan ejercicios propios sobre el estudio y profundización de las tecnologías CCNA, se desarrollan dos tareas asignadas definidas como escenarios, trabajando los diferentes temas propuestos y estudiados en el curso.

## **1 INTRODUCCION**

Se pretende realizar el proceso de ejecución de tareas vistas en el desarrollo de la materia, tales como: la configuración de diferentes dispositivos usados en los trabajos de Networking, estudiando el modelo OSI, la arquitectura TCP/IP y el uso de recursos. Además de conocer las diferentes herramientas en función de los protocolos y servicios.

Para lo cual se identifican y solucionan problemas relacionados a las subredes y direccionamientos de las identificaciones IP, para poder hacerlo se realiza el uso de comandos aprendidos y estudiados, se ejecutan las debidas configuraciones resolviendo los problemas establecidos, esto para garantizar la trasmisión de datos en los enlaces, suiches, dispositivos y rutas de información, se da solución a los diferentes escenarios usando las debidas técnicas de enrutamiento con el uso de comandos para el tráfico en las interfaces.

Finalmente se procede a documentar los diferentes procesos y protocolos exigidos en la configuración de cada uno de los dispositivos, además de mostrar las etapas realizadas durante su desarrollo, concluyendo la verificación de conectividad.

## **2 OBJETIVOS**

### **2.1 OBJETIVO GENERAL**

- Dar solución a los ejercicios designados como escenarios, usando los diferentes métodos de tecnologías CCNA, proponiendo en su desarrollo los temas estudiados en el curso.

### **2.2 OBJETIVOS ESPECÍFICOS**

- Se realizarán las debidas configuraciones de los dispositivos usado, la arquitectura TCP/IP
- Se ejecutarán los diferentes comandos y protocolos para resolver las configuraciones y problemas establecidos
- Se usarán temas de enrutamiento dinámico, protocolos OSPF y DHCP para poder hacer las diferentes configuraciones entre ciudades
- Se configurará los diferentes puertos además de realizar el encapsulamiento
- Se generará la seguridad en los Switches acorde a la topología solicitada
- Se realizará la configuración NAT permitiendo la salida a internet
- Se verificará procesos de comunicación y redireccionamiento de tráfico
- Se usará el protocolo RIP como enrutamiento además usando el encapsulamiento PPP y su debida autenticación

### 3 DESCRIPCION DEL ESCENARIO 1

Una empresa posee sucursales distribuidas en las ciudades de Bogotá y Medellín, en donde el estudiante será el administrador de la red, el cual deberá configurar e interconectar entre sí cada uno de los dispositivos que forman parte del escenario, acorde con los lineamientos establecidos para el direccionamiento IP, protocolos de enrutamiento y demás aspectos que forman parte de la topología de red.

Una empresa posee sucursales distribuidas en las ciudades de Bogotá y Medellín, en donde el estudiante será el administrador de la red, el cual deberá configurar e interconectar entre sí cada uno de los dispositivos que forman parte del escenario, acorde con los lineamientos establecidos para el direccionamiento IP, protocolos de enrutamiento y demás aspectos que forman parte de la topología de red.




Ilustración 1. Topología escenario 1

Este escenario plantea el uso de RIP como protocolo de enrutamiento, considerando que se tendrán rutas por defecto redistribuidas; asimismo, habilitar el encapsulamiento PPP y su autenticación.

Los routers Bogota2 y medellin2 proporcionan el servicio DHCP a su propia red LAN y a los routers 3 de cada ciudad.

Debe configurar PPP en los enlaces hacia el ISP, con autenticación.

Debe habilitar NAT de sobrecarga en los routers Bogota1 y medellin1.

Como trabajo inicial se debe realizar lo siguiente.

- Realizar las rutinas de diagnóstico y dejar los equipos listos para su configuración (asignar nombres de equipos, asignar claves de seguridad, etc).
- Realizar la conexión física de los equipos con base en la topología de red

Configurar la topología de red, de acuerdo con las siguientes especificaciones.

#### Parte 1: Configuración del enrutamiento

- a. Configurar el enrutamiento en la red usando el protocolo RIP versión 2, declare la red principal, desactive la sumarización automática.
- b. Los routers Bogota1 y Medellín deberán añadir a su configuración de enrutamiento una ruta por defecto hacia el ISP y, a su vez, redistribuirla dentro de las publicaciones de RIP.
- c. El router ISP deberá tener una ruta estática dirigida hacia cada red interna de Bogotá y Medellín para el caso se sumarizan las subredes de cada uno a /22.

#### Parte 2: Tabla de Enrutamiento.

- a. Verificar la tabla de enrutamiento en cada uno de los routers para comprobar las redes y sus rutas.
- b. Verificar el balanceo de carga que presentan los routers.

- c. Obsérvese en los routers Bogotá1 y Medellín1 cierta similitud por su ubicación, por tener dos enlaces de conexión hacia otro router y por la ruta por defecto que manejan.
- d. Los routers Medellín2 y Bogotá2 también presentan redes conectadas directamente y recibidas mediante RIP.
- e. Las tablas de los routers restantes deben permitir visualizar rutas redundantes para el caso de la ruta por defecto.
- f. El router ISP solo debe indicar sus rutas estáticas adicionales a las directamente conectadas.

#### Parte 3: Deshabilitar la propagación del protocolo RIP.

- a. Para no propagar las publicaciones por interfaces que no lo requieran se debe deshabilitar la propagación del protocolo RIP, en la siguiente tabla se indican las interfaces de cada router que no necesitan desactivación.

ROUTER	INTERFAZ
Bogota1	SERIAL0/0/1; SERIAL0/1/0; SERIAL0/1/1
Bogota2	SERIAL0/0/0; SERIAL0/0/1
Bogota3	SERIAL0/0/0; SERIAL0/0/1; SERIAL0/1/0
Medellín1	SERIAL0/0/0; SERIAL0/0/1; SERIAL0/1/1
Medellín2	SERIAL0/0/0; SERIAL0/0/1
Medellín3	SERIAL0/0/0; SERIAL0/0/1; SERIAL0/1/0
ISP	No lo requiere

#### Parte 4: Verificación del protocolo RIP.

- a. Verificar y documentar las opciones de enrutamiento configuradas en los routers, como el passive interface para la conexión hacia el ISP, la versión de RIP y las interfaces que participan de la publicación entre otros datos.

- b. Verificar y documentar la base de datos de RIP de cada router, donde se informa de manera detallada de todas las rutas hacia cada red.

Parte 5: Configurar encapsulamiento y autenticación PPP.

- a. Según la topología se requiere que el enlace Medellín1 con ISP sea configurado con autenticación PAT.
- b. El enlace Bogotá1 con ISP se debe configurar con autenticación CHAT.

Parte 6: Configuración de PAT.


- a. En la topología, si se activa NAT en cada equipo de salida (Bogotá1 y Medellín1), los routers internos de una ciudad no podrán llegar hasta los routers internos en el otro extremo, sólo existirá comunicación hasta los routers Bogotá1, ISP y Medellín1.
- b. Despues de verificar lo indicado en el paso anterior proceda a configurar el NAT en el router Medellín1. Compruebe que la traducción de direcciones indique las interfaces de entrada y de salida. Al realizar una prueba de ping, la dirección debe ser traducida automáticamente a la dirección de la interfaz serial 0/1/0 del router Medellín1, como diferente puerto.
- c. Proceda a configurar el NAT en el router Bogotá1. Compruebe que la traducción de direcciones indique las interfaces de entrada y de salida. Al realizar una prueba de ping, la dirección debe ser traducida automáticamente a la dirección de la interfaz serial 0/1/0 del router Bogotá1, como diferente puerto.

Parte 7: Configuración del servicio DHCP.

- a. Configurar la red Medellín2 y Medellín3 donde el router Medellín 2 debe ser el servidor DHCP para ambas redes Lan.

- b. El router Medellín3 deberá habilitar el paso de los mensajes broadcast hacia la IP del router Medellín2.
- c. Configurar la red Bogotá2 y Bogotá3 donde el router Medellín2 debe ser el servidor DHCP para ambas redes Lan.
- d. Configure el router Bogotá1 para que habilite el paso de los mensajes Broadcast hacia la IP del router Bogotá2.

### 3.1 DESARROLLO ESCENARIO 1



*Ilustración 2. Desarrollo de la topología escenario 1*

#### 3.1.1 CONFIGURACION DEL DIRECCIONAMIENTO

#### 3.1.2 CONFIGURACION DEL ISP

```
Router>enable
Router#conf t
^
```

```

% Invalid input detected at '^' marker.
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int s0/0/0
Router(config-if)#ip address 209.17.220.1 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/0, changed state to down
Router(config-if)#int s0/0/1
Router(config-if)#ip address 209.17.220.5 255.255.255.252
Router(config-if)#
Router#
%SYS-5-CONFIG_I: Configured from console by console

Router#clock rate 4000000
^
% Invalid input detected at '^' marker.
Router#int s0/0/1
^
% Invalid input detected at '^' marker.
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int s0/0/1
Router(config-if)#ip address 209.17.220.5 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/1, changed state to down
Router(config-if)#
Router#
%SYS-5-CONFIG_I: Configured from console by console

```

### **3.1.3 CONFIGURACION MEDELLIN 1**

```

Router>ENABLE
Router#CONF TERM
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int s0/0/0
^
% Invalid input detected at '^' marker.
Router(config)#int s0/0/0
Router(config-if)#ip address 209.17.220.2 255.255.252

```

```

^
% Invalid input detected at '^' marker.
Router(config-if)#ip address 209.17.220.2 255.255.255.252
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up

Router(config-if)#int s0/0/1
Router(config-if)#ip address 172.29.6.1 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/1, changed state to down
Router(config-if)#int s1/0
^
% Invalid input detected at '^' marker.
Router(config-if)#int s0/1/0
Router(config-if)#ip address 172.29.6.9 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/1/0, changed state to down
Router(config-if)#int s0/1/1
^
% Invalid input detected at '^' marker.
Router(config-if)#int s0/1/1
Router(config-if)#ip address 172.29.6.13 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/1/1, changed state to down
Router(config-if)#

```

### **3.1.4 CONFIGURACION MEDELLIN 2**

```

Router>ENABLE
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int s/0/0/0
^

```

```

% Invalid input detected at '^' marker.
Router(config)#s/0/0/0
^
% Invalid input detected at '^' marker.
Router(config)#s0/0/0
^
% Invalid input detected at '^' marker.
Router(config)#int s0/0/0
Router(config-if)#ip address 172.29.6.2 255.255.252
^
% Invalid input detected at '^' marker.
Router(config-if)#ip address 172.29.6.2 255.255.255.252
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up

Router(config-if)#int s0/0/1
Router(config-if)#ip address 172.29.6.5 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/1, changed state to down
Router(config-if)#int g0/0
Router(config-if)#ip address 172.29.4.1 255.255.255.128
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0, changed state
to up

Router(config-if)#

```

### **3.1.5 CONFIGURACION MEDELLIN 3**

```

Router>enable
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int s0/0/0

```

```
Router(config-if)#ip address 172.29.6.10 255.255.255.252
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up

Router(config-if)#int s0/0/1
Router(config-if)#172.29.6.14 255.255.255.252
^
% Invalid input detected at '^' marker.
Router(config-if)#ip address 172.29.6.14 255.255.255.252
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/1, changed state to up

Router(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/1, changed state to up

Router(config-if)#int s0/1/0
Router(config-if)#ip address 172.29.6.6 255.255.255.252
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface Serial0/1/0, changed state to up

Router(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/1/0, changed state to up

Router(config-if)#int g0/0
Router(config-if)#ip address 172.29.4.129 255.255.255.128
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0, changed state to up

Router(config-if)#

```

### 3.1.6 CONFIGURACION BOGOTA 1

```
Router>enable
Router#cofigure terminal
^
% Invalid input detected at '^' marker.
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int s0/0/0
Router(config-if)#ip address 209.17.220.6 255.255.255.252
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up

Router(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up

Router(config-if)#int s0/0/1
Router(config-if)#ip address 172.29.3.9 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/1, changed state to down
Router(config-if)#
Router(config-if)#int s0/1/0
Router(config-if)#ip address 172.29.3.1 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/1/0, changed state to down
Router(config-if)#
Router(config-if)#int s0/1/1
Router(config-if)#ip address 172.29.3.5 255.255.255.252
Router(config-if)#clock rate 400000
Unknown clock rate
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/1/1, changed state to down
Router(config-if)#
Router(config-if)#+
```

### 3.1.7 CONFIGURACION BOGOTA 2

```
Router>enab
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#int s/0/0/0
^
% Invalid input detected at '^' marker.
Router(config)#s0/0/0
^
% Invalid input detected at '^' marker.
Router(config)#int s0/0/0
Router(config-if)#ip address 172.29.3.10 255.255.255.252
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up

Router(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up

Router(config-if)#s0/0/1
^
% Invalid input detected at '^' marker.
Router(config-if)#int s0/0/1
Router(config-if)#ip address 172.29.3.13 255.255.255.25
Bad mask 0xFFFFFFF19 for address 172.29.3.13
Router(config-if)#ip address 172.29.3.13 255.255.255.252
Router(config-if)#clock rate 4000000
Router(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/1, changed state to down
Router(config-if)#
Router(config-if)#int g0/0
Router(config-if)#ip address 172.29.1.1 255.255.255.252
Router(config-if)#ip address 172.29.1.1 255.255.255.0
Router(config-if)#int g0/0
Router(config-if)#ip address 172.29.1.1 255.255.255.0
Router(config-if)#no shutdown

Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet0/0, changed state to up
```

%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0, changed state to up

Router(config-if)#

### 3.1.8 CONFIGURACION BOGOTA 3

Router>ENAB

Router#CONF TERM

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#int s0/0/0

Router(config-if)#ip address 172.29.3.2 255.255.255.252

Router(config-if)#no shutdown

Router(config-if)#

%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up

Router(config-if)#

%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up

Router(config-if)#int s0/0/1

Router(config-if)#ip address 172.29.3.6 255.255.255.252

Router(config-if)#no shutdown

Router(config-if)#

%LINK-5-CHANGED: Interface Serial0/0/1, changed state to up

Router(config-if)#

%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/1, changed state to up

Router(config-if)#int g0/0

Router(config-if)#ip address 172.29.0.1 255.255.255.0

Router(config-if)#no shutdown

Router(config-if)#

%LINK-5-CHANGED: Interface GigabitEthernet0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0, changed state to up

Router(config-if)#

### **3.2 CONFIGURACION DE RIP COMO PROTOCOLO DE ENRUTAMIENTO**

### **3.2.1 MEDELLIN 1**

Router>ena

Router#conf term

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#router

% Incomplete command.

Router(config)#router rip

Router(config-router)#version 2

```
Router(config-router)#no auto-summary
```

```
Router(config-router)#do show ip route connected
```

```
Router(config Router) # do show ip route connected  
C 172.29.6.0/30 is directly connected, Serial0/0/1
```

C 172.29.6.8/30 is directly connected, Serial0/1/0

C 172.29.6.12/30 is directly connected, Serial0/1

C 172.29.6.12/30 is directly connected, Ser


```
Router(config-router)#network 172.29.6.0
```

```
Router(config-router)#network 172.29.0.0  
Router(config-router)#network 172.29.6.8
```

```
Router(config-router)#network 172.29.0.8  
Router(config-router)#network 172.29.6.12
```

Router(config-router)#

Router(config-router)#]



### *Ilustración 3 Configuración RIP para Medellín 1*

### 3.2.2 MEDELLIN 2

```
Router>EN
Router#CINF TERM
^
% Invalid input detected at '^' marker.
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#router rip
Router(config-router)#version 2
Router(config-router)#no auto-summary
Router(config-router)#do show ip route connected
C 172.29.4.0/25 is directly connected, GigabitEthernet0/0
C 172.29.6.0/30 is directly connected, Serial0/0/0
C 172.29.6.4/30 is directly connected, Serial0/0/1
Router(config-router)#network 172.29.4.0
Router(config-router)#network 172.29.6.0
Router(config-router)#network 172.29.6.4
Router(config-router)#passive-interface g0/0
^
% Invalid input detected at '^' marker.
Router(config-router)#+3
^
% Invalid input detected at '^' marker.
Router(config-router)#passive-interface g0/0
Router(config-router)#

```





Ilustración 4 Configuración RIP para Medellín 2

### **3.2.3 MEDELLIN 3**



*Ilustración 5 Configuración RIP para Medellín 3*

### **3.2.4 BOGOTA 1**



### *Ilustración 6 Configuración RIP para Bogota 1*

### 3.2.5 BOGOTA 2

Router#conf term

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#router rip

Router(config-router)#version 2

Router(config-router)#no auto-summary

Router(config-router)#do show ip route connected

C 172.29.1.0/24 is directly connected, GigabitEthernet0/0

C 172.29.3.8/30 is directly connected, Serial0/0/0

C 172.29.3.12/30 is directly connected, Serial0/0/1

Router(config-router)#network 172.29.1.0

Router(config-router)#network 172.29.3.8

Router(config-router)#network 172.29.3.12

Router(config-router)#passive-interface g0/0

Router(config-router)#[/p]

The screenshot shows a Windows Command Line Interface window titled "Bogota 2". The window has tabs for "Physical" and "CLI", with "CLI" selected. The title bar also displays "Bogota 2". The main area is labeled "IOS Command Line Interface". The terminal window displays the following configuration commands:

```
*LINK-5-CHANGED: Interface Serial0/0/1, changed state to up
*LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/1, changed
state to up

Router>ena
Router#router rip
^
* Invalid input detected at '^' marker.

Router#conf term
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)#router rip
Router(config-router)#version 2
Router(config-router)#no auto-summary
Router(config-router)#do show ip route connected
C 172.29.1.0/24  is directly connected, GigabitEthernet0/0
C 172.29.3.8/30 is directly connected, Serial0/0/0
C 172.29.3.12/30 is directly connected, Serial0/0/1
Router(config-router)#network 172.29.1.0
Router(config-router)#network 172.29.3.8
Router(config-router)#network 172.29.3.12
Router(config-router)#passive-interface g0/0
Router(config-router)#[/p]
```

At the bottom of the window are "Copy" and "Paste" buttons. The taskbar at the bottom of the screen shows icons for File Explorer, Task View, and a search bar, along with system status indicators like battery level and date/time (03:40 p.m., 20/05/2019).

Ilustración 7 Configuración RIP para Bogota 2

### 3.2.6 BOGOTA 3

```
Router(config-if)#router rip
Router(config-router)#version 2
Router(config-router)#no auto-summary
Router(config-router)#do show ip route connected
C 172.29.0.0/24 is directly connected, GigabitEthernet0/0
C 172.29.3.0/30 is directly connected, Serial0/0/0
C 172.29.3.4/30 is directly connected, Serial0/0/1
C 172.29.3.12/30 is directly connected, Serial0/1/0
Router(config-router)#network 172.29.0.0
Router(config-router)##network 172.29.3.0
^
% Invalid input detected at '^' marker.
Router(config-router)##network 172.29.0.0
^
% Invalid input detected at '^' marker.
Router(config-router)#network 172.29.0.0
Router(config-router)#network 172.29.3.0
Router(config-router)#network 172.29.3.4
Router(config-router)#network 172.29.3.12
Router(config-router)#passive-interface g0/0
Router(config-router)#

```




Ilustración 8 Configuración RIP para Bogotá 3

### 3.3 MOSTRANDO RUTAS Y ELEMENTOS DE LOS RUTERS BOGOTA Y MEDELLIN

The screenshot shows a Windows application window titled "Bogota 1" with two tabs: "Physical" and "CLI". The "CLI" tab is selected, displaying the "IOS Command Line Interface". The output of the command "show ip route" is shown, detailing various routes learned via BGP, OSPF, and direct connections. The interface includes standard Windows controls like "Copy" and "Paste", and a taskbar at the bottom.

```
IOS Command Line Interface

- BGP
  D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter
area
  N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type
2
  E1 - OSPF external type 1, E2 - OSPF external type 2, E -
EGP
  i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-
IS inter area
  * - candidate default, U - per-user static route, o - ODR
  P - periodic downloaded static route

Gateway of last resort is not set

      172.29.0.0/16 is variably subnetted, 9 subnets, 3 masks
R        172.29.0.0/24 [120/1] via 172.29.3.2, 00:00:10, Serial0/1/0
                           [120/1] via 172.29.3.6, 00:00:10, Serial0/1/1
R        172.29.1.0/24 [120/1] via 172.29.3.10, 00:00:15,
Serial0/0/1
C          172.29.3.0/30 is directly connected, Serial0/1/0
L          172.29.3.1/32 is directly connected, Serial0/1/0
C          172.29.3.4/30 is directly connected, Serial0/1/1
L          172.29.3.5/32 is directly connected, Serial0/1/1
C          172.29.3.8/30 is directly connected, Serial0/0/1
L          172.29.3.9/32 is directly connected, Serial0/0/1
R          172.29.3.12/30 [120/1] via 172.29.3.10, 00:00:15,
Serial0/0/1
                           [120/1] via 172.29.3.2, 00:00:10,
Serial0/1/0
```

Ilustración 9 Ruta de Bogota 1

```
Router>ENABLE
Router#SHOW IP ROUTE
Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B - BGP
      D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
      N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
      E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
      i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
      * - candidate default, U - per-user static route, o - ODR
      P - periodic downloaded static route

Gateway of last resort is not set

  172.29.0.0/16 is variably subnetted, 9 subnets, 3 masks
R    172.29.4.0/25 [120/1] via 172.29.6.2, 00:00:19, Serial0/0/1
R    172.29.4.128/25 [120/1] via 172.29.6.14, 00:00:17, Serial0/1/1
                  [120/1] via 172.29.6.10, 00:00:17, Serial0/1/0
C    172.29.6.0/30 is directly connected, Serial0/0/1
L    172.29.6.1/32 is directly connected, Serial0/0/1
R    172.29.6.4/30 [120/1] via 172.29.6.2, 00:00:19, Serial0/0/1
                  [120/1] via 172.29.6.14, 00:00:17, Serial0/1/1
                  [120/1] via 172.29.6.10, 00:00:17, Serial0/1/0
C    172.29.6.8/30 is directly connected, Serial0/1/0
L    172.29.6.9/32 is directly connected, Serial0/1/0
C    172.29.6.12/30 is directly connected, Serial0/1/1
--More-- |
```

Ilustración 10 Ruta de Medellin 1

## 3.4 RUTA POR DEFECTO HACIA EL ISP

### 3.4.1 MEDELLIN

Router#conf term

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#ip 0.0.0.0 0.0.0.0 209.17.220.1

^

```
% Invalid input detected at '^' marker.
Router(config)#ip route 0.0.0.0 0.0.0.0 209.17.220.1
Router(config)#router rip
Router(config-router)#default-information originate
Router(config-router)#

```

```

Router>enable
Router#show ip route
Codes: L - local, C - connected, S - static, R - RIP, M - mobile,
      B - BGP
                  D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter
area
      N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external
type 2
      E1 - OSPF external type 1, E2 - OSPF external type 2, E -
EGP
      i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia -
IS-IS inter area
      * - candidate default, U - per-user static route, o - ODR
      P - periodic downloaded static route

Gateway of last resort is 172.29.6.1 to network 0.0.0.0

      172.29.0.0/16 is variably subnetted, 9 subnets, 3 masks
C        172.29.4.0/25 is directly connected, GigabitEthernet0/0
L        172.29.4.1/32 is directly connected, GigabitEthernet0/0
R        172.29.4.128/25 [120/1] via 172.29.6.6, 00:00:00,
Serial0/0/1
C        172.29.6.0/30 is directly connected, Serial0/0/0
L        172.29.6.2/32 is directly connected, Serial0/0/0
C        172.29.6.4/30 is directly connected, Serial0/0/1
L        172.29.6.5/32 is directly connected, Serial0/0/1
R        172.29.6.8/30 [120/1] via 172.29.6.1, 00:00:08,
Serial0/0/0
                                [120/1] via 172.29.6.6, 00:00:00,
Serial0/0/1
R        172.29.6.12/30 [120/1] via 172.29.6.1, 00:00:08,
Serial0/0/0
                                [120/1] via 172.29.6.6, 00:00:00,
Serial0/0/1
--More-- |
```

Ilustración 11 Ruta por defecto Medellin 2

### 3.4.2 BOGOTA

```
Router>ENABLE
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
```

```

Router(config)#ip route 0.0.0.0 0.0.0.0 209.17.220.5
Router(config)#router rip
Router(config-router)#default-information originate
Router(config-router)#

```

```

Router>enable
Router#show ip route
Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B -
BGP
      D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
      N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
      E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
      i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS
      inter area
      * - candidate default, U - per-user static route, o - ODR
      p - periodic downloaded static route

Gateway of last resort is 172.29.3.9 to network 0.0.0.0

      172.29.0.0/16 is variably subnetted, 9 subnets, 3 masks
R        172.29.0.0/24 [120/1] via 172.29.3.14, 00:00:13, Serial0/0/1
C        172.29.1.0/24 is directly connected, GigabitEthernet0/0
L        172.29.1.1/32 is directly connected, GigabitEthernet0/0
R        172.29.3.0/30 [120/1] via 172.29.3.9, 00:00:05, Serial0/0/0
                  [120/1] via 172.29.3.14, 00:00:13, Serial0/0/1
R        172.29.3.4/30 [120/1] via 172.29.3.9, 00:00:05, Serial0/0/0
                  [120/1] via 172.29.3.14, 00:00:13, Serial0/0/1
C        172.29.3.8/30 is directly connected, Serial0/0/0
L        172.29.3.10/32 is directly connected, Serial0/0/0
C        172.29.3.12/30 is directly connected, Serial0/0/1
L        172.29.3.13/32 is directly connected, Serial0/0/1
--More-- |

```

Copy      Paste

04:17 p.m.  
20/05/2019

Ilustración 12 Ruta por defecto Bogota 2

### 3.5 ROUTER ISP CON RUTA ESTÁTICA

Router#

```
Router#conf term  
Enter configuration commands, one per line. End with CNTL/Z.  
Router(config)#ip route 172.29.4.0 255.255.252.0 209.17.220.2  
Router(config)#ip route 172.29.0.0 255.255.252.0 209.17.220.6  
Router(config)#
```

The screenshot shows a Windows-style application window titled "Bogota 2". The window has two tabs at the top: "Physical" and "CLI", with "CLI" being the active tab. The main area is labeled "IOS Command Line Interface". The terminal session output is as follows:

```
L      172.29.3.13/32 is directly connected, Serial0/0/1
--More--

Router con0 is now available

Press RETURN to get started.

Router>enable
Router#ping 172.29.3.1

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.29.3.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/9/21 ms

Router#
```

At the bottom right of the terminal window, there are "Copy" and "Paste" buttons.

Ilustración 13 Ruta estatica Bogota 2

### 3.6 BALANCEO DE CARGA Y VISUALIZACION DE RUTAS REDUNDANTES

The screenshot shows a Windows application window titled "Medellin 3" with two tabs: "Physical" and "CLI". The "CLI" tab is selected, displaying the "IOS Command Line Interface". The output of the "SHOW IP ROUTE" command is shown, listing various routes including local, connected, static, and dynamic routes. The output highlights several redundant routes via Serial interfaces.

```
% Invalid input detected at '^' marker.

Router>ENABLE
Router#SHOW IP ROUTE
Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B -
BGP
      D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
      N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
      E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
      i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS
      inter area
      * - candidate default, U - per-user static route, o - ODR
      P - periodic downloaded static route

Gateway of last resort is 172.29.6.13 to network 0.0.0.0

      172.29.0.0/16 is variably subnetted, 10 subnets, 3 masks
R        172.29.4.0/25 [120/1] via 172.29.6.5, 00:00:02, Serial0/1/0
C        172.29.4.128/25 is directly connected, GigabitEthernet0/0
L        172.29.4.129/32 is directly connected, GigabitEthernet0/0
R        172.29.6.0/30 [120/1] via 172.29.6.13, 00:00:21, Serial0/0/1
                  [120/1] via 172.29.6.5, 00:00:02, Serial0/1/0
                  [120/1] via 172.29.6.9, 00:00:21, Serial0/0/0
C        172.29.6.4/30 is directly connected, Serial0/1/0
L        172.29.6.6/32 is directly connected, Serial0/1/0
C        172.29.6.8/30 is directly connected, Serial0/0/0
L        172.29.6.10/32 is directly connected, Serial0/0/0
C        172.29.6.12/30 is directly connected, Serial0/0/1
--More-- |
```

Copy      Paste

Ilustración 14Ruta redundante Medellin 3

### 3.7 CONFIGURACION ENCAPSULAMIENTO Y AUTENTICACIÓN PPP

#### 3.7.1 ISP

```
Router>ENAB
Router#conf term
```

```

Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#host name ISP
 ^
% Invalid input detected at '^' marker.
Router(config)#HOSTNAME ISP
ISP(config)#
ISP(config)#username medellin password medellin123
ISP(config)#
ISP(config)#int s0/0/0
ISP(config-if)#encapsulation ppp
ISP(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to
down

ISP(config-if)#ppp authentication pap
 ^
% Invalid input detected at '^' marker.
ISP(config-if)#ppp authentication pap
ISP(config-if)#ppp pap sent-username ISP password medellin123
ISP(config-if)#

```

### **3.7.2 MEDELLIN**

```

Router>ENABLE
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#hostname medellin
medellin(config)#username ISP password medellin123
medellin(config)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to
down

medellin(config)#int s0/0/0
medellin(config-if)#encapsulation ppp
medellin(config-if)#ppp authentication pap
medellin(config-if)#ppp pap sent-username medellin password medellin123
medellin(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up

medellin(config-if)#

```

**Medellin 1**

Physical    CLI

IOS Command Line Interface

```

medellin#ping 209.17.220.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 209.17.220.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/6/19 ms

medellin#ping 209.17.220.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 209.17.220.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/6/14 ms

medellin#ping 209.17.220.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 209.17.220.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/13/20 ms

medellin#ping 209.17.220.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 209.17.220.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/8/21 ms

medellin#

```

**Copy**    **Paste**

Ilustración 15 Encapsulamiento y autenticación PPP Medellín 1




Ilustración 16 Verificación de las diferentes redes

## 3.8 CONFIGURACIÓN DEL SERVICIO DHCP

### 3.8.1 MEDELLIN

```
Router>enable
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip dhcp excluded-address 172.29.4.1 172.29.4.5
^
% Invalid input detected at '^' marker.
Router(config)#ip dhcp excluded-address 172.29.4.1 172.29.4.5
Router(config)#ip dhcp excluded-address 172.29.4.129 172.29.4.133
Router(config)#ip dhcp pool med123
Router(dhcp-config)#network 172.29.4.0 255.255.255.128
Router(dhcp-config)#default-router 172.29.4.1
Router(dhcp-config)#dns-server 8.8.8.8
Router(dhcp-config)#exit
Router(config)#dhcp pool med1234
^
% Invalid input detected at '^' marker.
Router(config)#ip dhcp pool med1234
Router(dhcp-config)#network 172.29.4.128 255.255.255.128
Router(dhcp-config)#default-router 172.29.4.129
Router(dhcp-config)#dns-server 8.8.8.8
```




Ilustración 17 Servicio DHCP PCB

```
Router>ENABLE
```

```
Router#CONF TERM  
Enter configuration commands, one per line. End with CNTL/Z.  
Router(config)#int g0/0  
Router(config-if)#ip helper-address 172.29.6.5  
Router(config-if)#
```




Ilustración 18 servicio DHCP PC1

### 3.8.2 BOGOTA

```
Router>ENABLE  
Router#conf term  
Enter configuration commands, one per line. End with CNTL/Z.
```

```
Router(config)#ip dhcp excluded-address 172.29.1.1 172.29.1.5
Router(config)#ip dhcp excluded-address 172.29.0.1 172.29.0.5
Router(config)#ip dhcp pool bog123
Router(dhcp-config)#network 172.29.1.0 255.255.255.0
Router(dhcp-config)#default-router 172.29.1.1
Router(dhcp-config)#dns-server 8.8.8.8
Router(dhcp-config)#ip dhcp pool bog1234
Router(dhcp-config)#network 172.29.0.0 255.255.255.0
Router(dhcp-config)#default-router 172.29.0.1
Router(dhcp-config)#dns-server 8.8.8.8
Router(dhcp-config)#

```




Ilustración 19 Servicio DHCP PC3

```
Router>enable  
Router#conf term  
Enter configuration commands, one per line. End with CNTL/Z.  
Router(config)#int g0/0  
Router(config-if)#ip helper-address 172.29.3.13  
Router(config-if)#
```




Ilustración 20 Servicio DHCP PC2

### 3.9 PING ENTRE PC




Ilustración 21 Ping en PC2




Ilustración 22 Ping PC

### 3.10 CONFIGURACION PAT

#### 3.10.1 MEDELLIN

```
medellin>enable
medellin#conf term
```

Enter configuration commands, one per line. End with CNTL/Z.  
medellin(config)#ip nat inside source list 1 interface s0/0/0 overload  
medellin(config)#access-list 1 permit 172.29.4.0 0.0.0.3.255  
^  
% Invalid input detected at '^' marker.

```
medellin(config)#access-list 1 permit 172.29.4.0 0.0.3.255
medellin(config)#int s0/0/0
medellin(config-if)#ip nat outside
medellin(config-if)#int s0/0/1
medellin(config-if)#ip nat inside
medellin(config-if)#int s0/1/0
medellin(config-if)#ip nat inside
medellin(config-if)#int s0/1/1
medellin(config-if)#ip nat inside
medellin(config-if)#

```

### **3.10.2 BOGOTA**

A screenshot of the Packet Tracer software interface. The window title is "PC1". Inside, there are tabs for "Physical", "Desktop", and "Custom Interface", with "Physical" selected. Below the tabs is a "Command Prompt" window titled "Command Prompt". The command entered is "ping 172.29.4.6". The output shows the ping process: "Pinging 172.29.4.6 with 32 bytes of data:", followed by four replies from the target IP, and finally ping statistics indicating 0% loss. The command prompt ends with "pc>".

```
Packet Tracer PC Command Line 1.0
PC>ping 172.29.4.6

Pinging 172.29.4.6 with 32 bytes of data:

Reply from 172.29.4.6: bytes=32 time=1ms TTL=126
Reply from 172.29.4.6: bytes=32 time=15ms TTL=126
Reply from 172.29.4.6: bytes=32 time=1ms TTL=126
Reply from 172.29.4.6: bytes=32 time=1ms TTL=126

Ping statistics for 172.29.4.6:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 15ms, Average = 4ms

PC>
```

Ilustración 23 Ping PC1

### Aqui el ping debe fallar

A screenshot of the Packet Tracer software interface, similar to Illustration 23. The window title is "PC1". Inside, there are tabs for "Physical", "Desktop", and "Custom Interface", with "Physical" selected. Below the tabs is a "Command Prompt" window titled "Command Prompt". The command entered is "ping 172.29.1.6". The output shows the ping process: "Pinging 172.29.1.6 with 32 bytes of data:", followed by four replies from the target IP, and finally ping statistics indicating 100% loss. The command prompt ends with "pc>".

```
Packet Tracer PC Command Line 1.0
PC>ping 172.29.4.6

Pinging 172.29.4.6 with 32 bytes of data:

Reply from 172.29.4.6: bytes=32 time=1ms TTL=126
Reply from 172.29.4.6: bytes=32 time=15ms TTL=126
Reply from 172.29.4.6: bytes=32 time=1ms TTL=126
Reply from 172.29.4.6: bytes=32 time=1ms TTL=126

Ping statistics for 172.29.4.6:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 15ms, Average = 4ms

PC>ping 172.29.1.6

Pinging 172.29.1.6 with 32 bytes of data:

Reply from 172.29.4.129: Destination host unreachable.

Ping statistics for 172.29.1.6:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
    PC>
```

Ilustración 24 Ping fallando en PC1

## **3.11 ASIGNACION DE CLAVES DE SEGURIDAD**

### **3.11.1 MEDELLIN**

```
Router>enable
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#no ip domain-lookup
Router(config)#service password-encryption
Router(config)#enable secret class
Router(config)#banner motd %john bustos%
Router(config)#line console 0
Router(config-line)#password escenario1
Router(config-line)#login
Router(config-line)#hostname medellin2
medellin2(config)#
medellin2(config)#+
```

### **3.11.2 BOGOTA**

```
Router(config)#
Router(config)#no ip domain-lookup
Router(config)#service password-encryption
Router(config)#enable secret class
Router(config)#banner motd %john bustos%
Router(config)#line console 0
Router(config-line)#password escenario1
Router(config-line)#login
Router(config-line)#hostname bogota2
```

## **4 DESCRIPCION DEL ESCENARIO 2**




Ilustración 25 Topología escenario 2

Escenario: Una empresa de Tecnología posee tres sucursales distribuidas en las ciudades de Miami, Bogotá y Buenos Aires, en donde el estudiante será el administrador de la red, el cual deberá configurar e interconectar entre sí cada uno de los dispositivos que forman parte del escenario, acorde con los lineamientos establecidos para el direccionamiento IP, protocolos de enrutamiento y demás aspectos que forman parte de la topología de red.

1. Configurar el direccionamiento IP acorde con la topología de red para cada uno de los dispositivos que forman parte del escenario
2. Configurar el protocolo de enrutamiento OSPFv2 bajo los siguientes criterios:

OSPFv2 area 0

Configuration Item or TaskSpecification

Router ID R11.1.1.1

Router ID R25.5.5.5

Router ID R38.8.8.8

Configurar todas las interfaces LAN como pasivas

Establecer el ancho de banda para enlaces seriales en 256 Kb/s

Ajustar el costo en la métrica de S0/0 a 9500

Verificar información de OSPF

- Visualizar tablas de enrutamiento y routers conectados por OSPFv2
- Visualizar lista resumida de interfaces por OSPF en donde se ilustre el costo de cada interface
- Visualizar el OSPF Process ID, Router ID, Address summarizations, Routing Networks, and passive interfaces configuradas en cada router.

3. Configurar VLANs, Puertos troncales, puertos de acceso, encapsulamiento, Inter-VLAN Routing y Seguridad en los Switches acorde a la topología de red establecida.

4. En el Switch 3 deshabilitar DNS lookup
5. Asignar direcciones IP a los Switches acorde a los lineamientos.
6. Desactivar todas las interfaces que no sean utilizadas en el esquema de red.
7. Implement DHCP and NAT for IPv4
8. Configurar R1 como servidor DHCP para las VLANs 30 y 40.
9. Reservar las primeras 30 direcciones IP de las VLAN 30 y 40 para configuraciones estáticas.

Configurar DHCP pool para VLAN 30 Name: ADMINISTRACION

DNS-Server: 10.10.10.11

Domain-Name: ccna-unad.com

Establecer default gateway.

Configurar DHCP pool para VLAN 40 Name: MERCADERO

DNS-Server: 10.10.10.11

Domain-Name: ccna-unad.com

Establecer default gateway.

10. Configurar NAT en R2 para permitir que los host puedan salir a internet

11. Configurar al menos dos listas de acceso de tipo estándar a su criterio en para restringir o permitir tráfico desde R1 o R3 hacia R2.

12. Configurar al menos dos listas de acceso de tipo extendido o nombradas a su criterio en para restringir o permitir tráfico desde R1 o R3 hacia R2.

13. Verificar procesos de comunicación y redireccionamiento de tráfico en los routers mediante el uso de Ping y Traceroute.

## 4.1 DESARROLLO ESCENARIO 2




Ilustración 26 Desarrollo de la topología escenario 2

## **4.2 CONFIGURACIÓN BASICA**

### **4.2.1 R1**

Router>ENABLE

```
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#hostname bogota
bogota(config)#no ip domain-lookup
bogota(config)#enable secret class
bogota(config)#line console 0
bogota(config-line)#password cisco
bogota(config-line)#login
bogota(config-line)#line vty 0 15
bogota(config-line)#password cisco
bogota(config-line)#login
bogota(config-line)#exit
bogota(config)#service password-encryption
bogota(config)#banner motd $acceso no permitido$
bogota(config)#+
```

### **4.2.2 R2**

```
Router>enable
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#hostname miami
miami(config)#no ip domain-lookup
miami(config)#enable secret class
miami(config)#line console 0
miami(config-line)#password cisco
miami(config-line)#login
miami(config-line)#line vty 0 15
miami(config-line)#password cisco
miami(config-line)#login
miami(config-line)#exit
miami(config)#service password-encryption
miami(config)#banner motd $acceso no permitido$
miami(config)#+
```

#### **4.2.3 R3**

```
Router>enable
Router#conf term
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#hostname buenosaires
buenosaires(config)#no ip domain-lookup
buenosaires(config)#enable secret class
buenosaires(config)#line console 0
buenosaires(config-line)#password cisco
buenosaires(config-line)#login
buenosaires(config-line)#line vty 0 15
buenosaires(config-line)#password cisco
buenosaires(config-line)#login
buenosaires(config-line)#exit
buenosaires(config)#service password-encryption
buenosaires(config)#banner motd $acceso no permitido$
buenosaires(config)#+
```

#### **4.2.4 S1**

```
Switch>ENABLE
Switch#conf termin
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#hosname S1
^
% Invalid input detected at '^' marker.
Switch(config)#hostname S1
S1(config)#no ip domain-lookup
S1(config)#enable secret class
S1(config)#line console 0
S1(config-line)#password cisco
S1(config-line)#login
S1(config-line)#line vty 0 15
S1(config-line)#password cisco
S1(config-line)#login
S1(config-line)#exit
S1(config)#service password-encryption
S1(config)#banner motd $acceso no permitido$
S1(config)#+
```

#### 4.2.5 S3

```
Switch>ENABLE
Switch#CONF TERM
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#hostname S3
S3(config)#no ip domain-lookup
S3(config)#enable secret class
S3(config)#line console 0
S3(config-line)#password cisco
S3(config-line)#login
S3(config-line)#line vty 0 15
S3(config-line)#password cisco
S3(config-line)#login
S3(config-line)#exit
S3(config)#service password-encryption
S3(config)#banner motd $acceso no permitido
Enter TEXT message. End with the character '$'.
```

```
S3(config)##banner motd $acceso no permitido$  
^  
% Invalid input detected at '^' marker.  
S3(config)#banner motd $acceso no permitido$  
S3(config)#+
```

### 4.3 CONFIGURACION DEL DIRECCIONAMIENTO IP




Ilustración 27 Configuración IP PC




Ilustración 28 Configuración IP Servidor

#### 4.3.1 R1

```
bogota>enable
bogota#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
bogota(config)#interface Serial0/0/0
bogota(config-if)#no shutdown
```

```
%LINK-5-CHANGED: Interface Serial0/0/0, changed state to down
```

```
bogota(config-if)#clock rate 128000
bogota(config-if)#ip address 172.31.21.1 255.255.255.252
bogota(config-if)#exit
bogota(config)#exit
bogota#
%SYS-5-CONFIG_I: Configured from console by console
```

```
bogota#copy running-config startup-config
Destination filename [startup-config]? ok
%Error copying nvram:ok (Invalid argument)
bogota#
```

### 4.3.2 R2

```
miami>ENABLE
miami#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
miami(config)#interface Serial0/0/1
miami(config-if)#no shutdown

miami(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/1, changed state to up

miami(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/1, changed state to up

00:24:03: %OSPF-5-ADJCHG: Process 1, Nbr 1.1.1.1 on Serial0/0/1 from LOADING to
FULL, Loading Done

miami(config-if)#no clock rate
This command applies only to DCE interfaces
miami(config-if)#ip address 172.31.21.2 255.255.255.252
miami(config-if)#exit
miami(config)#interface Serial0/0/0
miami(config-if)#no shutdown

%LINK-5-CHANGED: Interface Serial0/0/0, changed state to down
miami(config-if)##clock rate 128000
^
% Invalid input detected at '^' marker.
miami(config-if)#clock rate 128000
miami(config-if)#ip address 172.31.23.2 255.255.255.252
miami(config-if)#exit
```

```

miami(config)#interface GigabitEthernet0/0
%Invalid interface type and number
miami(config)#interface GigabitEthernet0/0
%Invalid interface type and number
miami(config)#INTERFACE fastEthernet0/0
miami(config-if)#no shutdown

miami(config-if)#
%LINK-5-CHANGED: Interface FastEthernet0/0, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state to
up
ip address 209.165.200.225 255.255.255.248
miami(config-if)#exit
miami(config)#interface GigabitEthernet0/1
%Invalid interface type and number
miami(config)#interface fastEthernet0/1
miami(config-if)#no shutdown

miami(config-if)#
%LINK-5-CHANGED: Interface FastEthernet0/1, changed state to up

miami(config-if)#ip address 10.10.10.1 255.255.255.0
miami(config-if)#exit
miami(config)#exit
miami#
%SYS-5-CONFIG_I: Configured from console by console

miami#

```

### 4.3.3 R3

```

buenosaires>enable
buenosaires#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
buenosaires(config)#interface Serial0/0/1
buenosaires(config-if)#no clock rate
This command applies only to DCE interfaces
buenosaires(config-if)#no shutdown

buenosaires(config-if)#
%LINK-5-CHANGED: Interface Serial0/0/1, changed state to up

```

```
buenosaires(config-if)#  
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/1, changed state to up  
  
buenosaires(config-if)#ip address 172.31.23.1 255.255.255.252  
buenosaires(config-if)#  
00:35:15: %OSPF-5-ADJCHG: Process 1, Nbr 5.5.5.5 on Serial0/0/1 from LOADING to  
FULL, Loading Done  
  
buenosaires(config-if)#interface 104  
  
buenosaires(config-if)#  
%LINK-5-CHANGED: Interface Loopback4, changed state to up  
  
%LINEPROTO-5-UPDOWN: Line protocol on Interface Loopback4, changed state to up  
  
buenosaires(config-if)#ip address 192.168.4.1 255.255.255.0  
buenosaires(config-if)#no shutdown  
buenosaires(config-if)#interface 105  
  
buenosaires(config-if)#  
%LINK-5-CHANGED: Interface Loopback5, changed state to up  
  
%LINEPROTO-5-UPDOWN: Line protocol on Interface Loopback5, changed state to up  
  
buenosaires(config-if)#ip address 192.168.5.1 255.255.255.0  
buenosaires(config-if)#no shutdown  
buenosaires(config-if)#interface 106  
  
buenosaires(config-if)#  
%LINK-5-CHANGED: Interface Loopback6, changed state to up  
  
%LINEPROTO-5-UPDOWN: Line protocol on Interface Loopback6, changed state to up  
  
buenosaires(config-if)#ip address 192.168.6.1 255.255.255.0  
buenosaires(config-if)#no shutdown  
buenosaires(config-if)#exit  
buenosaires(config)#exit  
buenosaires#  
%SYS-5-CONFIG_I: Configured from console by console  
  
buenosaires#copy run  
% Incomplete command.  
buenosaires#copy running-config startup-config  
Destination filename [startup-config]? OK  
%Error copying nvram:OK (Invalid argument)
```

```
buenosaires#  
buenosaires#copy running-config startup-config  
Destination filename [startup-config]? ok  
%Error copying nvram:ok (Invalid argument)  
buenosaires#copy running-config startup-config  
Destination filename [startup-config]?  
Building configuration...  
[OK]  
buenosaires#
```

## 4.4 CONFIGURACION DE OSPFV2

### 4.4.1 R1

```
bogota#ENABLE  
bogota#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
bogota(config)#router ospf 1  
bogota(config-router)#router-id 1.1.1.1  
bogota(config-router)#Reload or use "clear ip ospf process" command, for this to take  
effect
```

```
bogota(config-router)#clear ip ospf process  
^  
% Invalid input detected at '^' marker.  
bogota(config-router)#clear ip ospf  
^  
% Invalid input detected at '^' marker.  
bogota(config-router)#router-id 1.1.1.1  
bogota(config-router)#Reload or use "clear ip ospf process" command, for this to take  
effect
```

```
bogota(config-router)#passive-interface fastEthernet 0/0  
bogota(config-router)#network 172.31.21.0 0.0.0.3 area 0  
bogota(config-router)#exit  
bogota(config)#interface serial 0/0/0  
bogota(config-if)#bandwidth 256  
bogota(config-if)#ip ospf cost 9500  
bogota(config-if)#exit
```

```
bogota(config)#exit  
bogota#  
%SYS-5-CONFIG_I: Configured from console by console  
  
bogota#
```

#### 4.4.2 R2

```
miami>ENABLE  
miami#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
miami(config)#router ospf 2  
miami(config-router)#router-id 5.5.5.5  
OSPF: router-id 5.5.5.5 in use by ospf process 1  
miami(config-router)#passive-interface FASTETHERNET 0/0  
miami(config-router)#passive-interface FASTEthernet 0/1  
miami(config-router)#network 172.31.21.0 0.0.0.3 area 0  
miami(config-router)#network 172.31.23.0 0.0.0.3 area 0  
miami(config-router)#exit  
miami(config)#interface serial 0/0/0  
miami(config-if)#bandwidth 256  
miami(config-if)#ip ospf cost 9500  
miami(config-if)#exit  
miami(config)#interface serial 0/0/1  
miami(config-if)#bandwidth 256  
miami(config-if)#ip ospf cost 9500  
miami(config-if)#EXIT  
miami(config)#EXIT  
miami#  
%SYS-5-CONFIG_I: Configured from console by console
```

```
miami#
```

#### 4.4.3 R3

```
buenosaires>  
buenosaires>  
buenosaires>  
buenosaires>ENA  
buenosaires#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
buenosaires(config)#router ospf 3
```

```

buenosaires(config-router)#router-id 8.8.8.8
OSPF: router-id 8.8.8.8 in use by ospf process 1
buenosaires(config-router)#passive-interface loop
% Incomplete command.
buenosaires(config-router)#passive-interface loopback 4
buenosaires(config-router)#passive-interface loopback 5
buenosaires(config-router)#passive-interface loopback 6
buenosaires(config-router)#network 172.31.23.0 0.0.0.3 area 0
buenosaires(config-router)#exit
buenosaires(config)#interface serial 0/0/1
buenosaires(config-if)#bandwidth 256
buenosaires(config-if)#ip ospf cost 9500
buenosaires(config-if)#EXIT
buenosaires(config)#EXIT
buenosaires#
%SYS-5-CONFIG_I: Configured from console by console

```

## 4.5 VISUALIZACION DE TABLAS DE ENRUTAMIENTO




Ilustración 29 Tablas de enrutamiento R1

R2

Physical    CLI

IOS Command Line Interface

```
Press RETURN to get started.

miami>enable
miami#show ip ospf neighbor

Neighbor ID      Pri   State            Dead Time    Address
Interface
1.1.1.1          0     FULL/        -           00:00:33    172.31.21.1
Serial0/0/1
8.8.8.8          0     FULL/        -           00:00:37    172.31.23.1
Serial0/0/0
miami#
```

Copy    Paste

The image shows a Windows operating system interface. At the top is a window titled 'R2' containing an 'IOS Command Line Interface'. The interface displays a command-line session where the user has entered 'enable' and then run 'show ip ospf neighbor'. The output lists two OSPF neighbors: one with IP 172.31.21.1 and another with IP 172.31.23.1. Below the window is a standard Windows taskbar with icons for Start, File Explorer, Task View, and others. The system tray shows icons for battery, volume, and network. The status bar at the bottom right indicates the date and time as '09:31 p.m. 21/05/2019'.

Ilustración 30 Tablas de enrutamiento R2




Ilustración 31 Tablas de enrutamiento R3

## 4.6 VISUALIZAR LISTA RESUMIDA DE INTERFACES POR OSPF

The screenshot shows a Windows desktop environment with a terminal window titled "R1". The window has tabs for "Physical" and "CLI", with "CLI" selected. The title bar says "IOS Command Line Interface". The main area displays the following output:

```
Neighbor ID      PII      State        Dead time     Address
Interface
5.5.5.5          0      FULL/      -           00:00:36    172.31.21.2
Serial0/0/0
bogota#
bogota#
bogota#enable show ip ospf interface
^
% Invalid input detected at '^' marker.

bogota#show ip ospf interface

Serial0/0/0 is up, line protocol is up
  Internet address is 172.31.21.1/30, Area 0
  Process ID 1, Router ID 1.1.1.1, Network Type POINT-TO-POINT,
Cost: 9500
  Transmit Delay is 1 sec, State POINT-TO-POINT, Priority 0
  No designated router on this network
  No backup designated router on this network
  Timer intervals configured, Hello 10, Dead 40, Wait 40,
Retransmit 5
    Hello due in 00:00:04
  Index 1/1, flood queue length 0
  Next 0x0(0)/0x0(0)
  Last flood scan length is 1, maximum is 1
  Last flood scan time is 0 msec, maximum is 0 msec
  Neighbor Count is 1 , Adjacent neighbor count is 1
    Adjacent with neighbor 5.5.5.5
  Suppress hello for 0 neighbor(s)
bogota#
```

At the bottom of the terminal window, there are "Copy" and "Paste" buttons. Below the terminal window is a taskbar with various icons and system status indicators.

Ilustración 32 Listas OSPF R1

R2

Physical CLI

### IOS Command Line Interface

```
1.1.1.1      0    FULL/ -      00:00:33    172.31.21.1
Serial0/0/1
8.8.8.8      0    FULL/ -      00:00:37    172.31.23.1
Serial0/0/0
miami#
miami#
miami#show ip interface
FastEthernet0/0 is up, line protocol is up (connected)
  Internet address is 209.165.200.225/29
  Broadcast address is 255.255.255.255
  Address determined by setup command
  MTU is 1500 bytes
  Helper address is not set
  Directed broadcast forwarding is disabled
  Outgoing access list is not set
  Inbound access list is not set
  Proxy ARP is enabled
  Security level is default
  Split horizon is enabled
  ICMP redirects are always sent
  ICMP unreachable messages are always sent
  ICMP mask replies are never sent
  IP fast switching is disabled
  IP fast switching on the same interface is disabled
  IP Flow switching is disabled
  IP Fast switching turbo vector
  IP multicast fast switching is disabled
  IP multicast distributed fast switching is disabled
  Router Discovery is disabled
--More--
```

Copy Paste



The taskbar at the bottom of the window shows various icons for system functions like file, edit, and search, along with a system tray icon for a network connection. The status bar displays the date and time as "09:37 p.m. 21/05/2019".

Ilustración 33 Listas OSP R2

## 4.7 VISUALIZACION DE ID

The screenshot shows a Windows application window titled "R1" containing the Cisco IOS Command Line Interface (CLI). The window has two tabs at the top: "Physical" (selected) and "CLI". The main area displays the output of the "show ip protocols" command:

```
Last flood scan length is 1, maximum is 1
Last flood scan time is 0 msec, maximum is 0 msec
Neighbor Count is 1 , Adjacent neighbor count is 1
    Adjacent with neighbor 5.5.5.5
    Suppress hello for 0 neighbor(s)
bogota#show ip protocols

Routing Protocol is "ospf 1"
    Outgoing update filter list for all interfaces is not set
    Incoming update filter list for all interfaces is not set
    Router ID 1.1.1.1
    Number of areas in this router is 1. 1 normal 0 stub 0 nssa
    Maximum path: 4
    Routing for Networks:
        172.31.21.0 0.0.0.3 area 0
        192.168.30.0 0.0.0.255 area 0
        192.168.40.0 0.0.0.255 area 0
        192.168.200.0 0.0.0.255 area 0
    Passive Interface(s):
        FastEthernet0/0
        FastEthernet0/0.30
        FastEthernet0/0.40
        FastEthernet0/0.200
    Routing Information Sources:
        Gateway          Distance      Last Update
        1.1.1.1           110          00:24:40
        5.5.5.5           110          00:23:37
        8.8.8.8           110          00:19:43
--More-- |
```

At the bottom of the CLI window, there are "Copy" and "Paste" buttons. Below the window, the Windows taskbar is visible, showing icons for File Explorer, Task View, Calculator, File History, Mail, and Task Scheduler, along with system status indicators like battery level, signal strength, and date/time (09:42 p.m., 21/05/2019).

Ilustración 34 Visualizacion ID R1

R2

Physical CLI

### IOS Command Line Interface

```
miami#
miami#
miami#
miami#
miami#
miami#
miami#
miami#show ip protocols

Routing Protocol is "ospf 1"
  Outgoing update filter list for all interfaces is not set
  Incoming update filter list for all interfaces is not set
  Router ID 5.5.5.5
  Number of areas in this router is 1. 1 normal 0 stub 0 nssa
  Maximum path: 4
  Routing for Networks:
    172.31.21.0 0.0.0.3 area 0
    172.31.23.0 0.0.0.3 area 0
    10.10.10.0 0.0.0.255 area 0
    172.31.31.0 0.0.0.3 area 0
  Passive Interface(s):
    FastEthernet0/1
  Routing Information Sources:
    Gateway          Distance      Last Update
    1.1.1.1           110          00:26:04
    5.5.5.5           110          00:25:00
    8.8.8.8           110          00:21:07
    Distance: (default is 110)

  Routing Protocol is "ospf 2"
--More--
```

Copy Paste



ES 09:43 p.m.  
21/05/2019

Ilustración 35 Visualización ID R2

The screenshot shows a Cisco Router's Command Line Interface (CLI) window titled "IOS Command Line Interface". The window is divided into two tabs: "Physical" and "CLI", with "CLI" selected. The main area displays the following command output:

```
buenosaires>enable  
buenosaires#show ip protocols  
  
Routing Protocol is "ospf 1"  
    Outgoing update filter list for all interfaces is not set  
    Incoming update filter list for all interfaces is not set  
    Router ID 8.8.8.8  
    Number of areas in this router is 1. 1 normal 0 stub 0 nssa  
    Maximum path: 4  
    Routing for Networks:  
        172.31.23.0 0.0.0.3 area 0  
        192.168.4.0 0.0.0.3 area 0  
    Passive Interface(s):  
        FastEthernet0/1  
    Routing Information Sources:  
        Gateway          Distance      Last Update  
        1.1.1.1           110          00:26:59  
        5.5.5.5           110          00:25:56  
        8.8.8.8           110          00:22:02  
    Distance: (default is 110)  
  
Routing Protocol is "ospf 3"  
    Outgoing update filter list for all interfaces is not set  
    Incoming update filter list for all interfaces is not set  
--More--
```

At the bottom of the CLI window, there are "Copy" and "Paste" buttons. Below the CLI window, the Windows taskbar is visible, showing icons for File Explorer, Task View, Start, and Settings, along with system status indicators like battery level, signal strength, and the date and time (09:44 p.m., 21/05/2019).

Ilustración 36 Visualización ID R3

## 4.8 CONFIGURACION AVANZADA SEGÚN TOPOLOGIA

### 4.8.1 S1

S1>  
S1>ENABLE

```

S1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
S1(config)#vlan 30
S1(config-vlan)#name Administracion
S1(config-vlan)#exit
S1(config)#vlan 40
S1(config-vlan)#name Mercadeo
S1(config-vlan)#exit
S1(config)#vlan 200
S1(config-vlan)#name
S1(config-vlan)#exit
S1(config)#interface FastEthernet0/1
S1(config-if)#switchport mode access
S1(config-if)#switchport access vlan 30
S1(config-if)#exit
S1(config)#interface FastEthernet0/3
S1(config-if)#switchport mode trunk

S1(config-if)#
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to
down

%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/3, changed state to
up

S1(config-if)#EXIT
S1(config)#interface FastEthernet0/24
S1(config-if)#switchport mode trunk
S1(config-if)#EXIT
S1(config)#

```

#### 4.8.2 S3

```

S3(config)#vlan 30
S3(config-vlan)#name Administracion
S3(config-vlan)#exit
S3(config)#40
^
% Invalid input detected at '^' marker.
S3(config)#vlan 40
S3(config-vlan)#name Mercadeo
S3(config-vlan)#exit
S3(config)#vlan 200

```

```
S3(config-vlan)#name Mantenimiento
S3(config-vlan)#exit
S3(config)#interface FastEthernet0/1
S3(config-if)#switchport mode access
S3(config-if)#switchport access vlan 40
S3(config-if)#exit
S3(config)#interface FastEthernet0/3
S3(config-if)#switchport mode trunk
S3(config-if)#exit
S3(config)#
S3(config)#

```

## 4.9 DIRECCIONES IP DE LOS SWITCHES

### 4.9.1 S1

```
S1>EN
S1#CONF TER
Enter configuration commands, one per line. End with CNTL/Z.
S1(config)#interface vlan 30
S1(config-if)#
%LINK-5-CHANGED: Interface Vlan30, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan30, changed state to up

S1(config-if)#ip address 192.168.99.2 255.255.255.0
% 192.168.99.0 overlaps with Vlan99
S1(config-if)#exit
S1(config)#ip default-gateway 192.168.99.1
S1(config)#exit
S1#
%SYS-5-CONFIG_I: Configured from console by console

```

### 4.9.2 S3

```
S3#ENA
S3#CONF TERM
Enter configuration commands, one per line. End with CNTL/Z.
S3(config)#interface vlan 40

```

```
S3(config-if)#
%LINK-5-CHANGED: Interface Vlan40, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan40, changed state to up

S3(config-if)#interface vlan 40
S3(config-if)#192.168.99.3 255.255.255.0
^
% Invalid input detected at '^' marker.
S3(config-if)#ip address 192.168.99.3 255.255.255.0
% 192.168.99.0 overlaps with Vlan99
S3(config-if)#exit
S3(config)#ip default-gateway 192.168.99.1
S3(config)#exit
S3#
%SYS-5-CONFIG_I: Configured from console by console
```

## 4.10 DESACTIVAR TODAS LAS INTERFACES

### 4.10.1 S1

```
S1>EN
S1#CONF TER
Enter configuration commands, one per line. End with CNTL/Z.
S1(config)#interface vlan 30
S1(config-if)#
%LINK-5-CHANGED: Interface Vlan30, changed state to up

%LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan30, changed state to up

S1(config-if)#ip address 192.168.99.2 255.255.255.0
% 192.168.99.0 overlaps with Vlan99
S1(config-if)#exit
S1(config)#ip default-gateway 192.168.99.1
S1(config)#exit
S1#
%SYS-5-CONFIG_I: Configured from console by console
```

```
S1#CONF TERM
Enter configuration commands, one per line. End with CNTL/Z.
S1(config)#interface fastEthernet 0/2
```

```

S1(config-if)#shutdown
S1(config-if)#exit
S1(config)#interface range fastEthernet 0/4-23
S1(config-if-range)#shutdonn
^
% Invalid input detected at '^' marker.
S1(config-if-range)#shutdown
S1(config-if-range)#
S1(config-if-range)#
S1(config-if-range)#exit
S1(config)#exit
S1#
%SYS-5-CONFIG_I: Configured from console by console

```

#### 4.10.2 S3

```

S3#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
S3(config)#inte fastEthernet 0/2
S3(config-if)#shutdown

%LINK-5-CHANGED: Interface FastEthernet0/2, changed state to administratively down
S3(config-if)#exit
S3(config)#interface range fastEthernet 0/4-24
S3(config-if-range)#shutdown

%LINK-5-CHANGED: Interface FastEthernet0/4, changed state to administratively down

```

#### 4.11 IMPLEMENTACION DE DHCP NAT



Ilustración 37 DHCP NAT PC-A




Ilustración 38 DHCP NAT PC-C

## 4.12 CONFIGURACION DE SERVIDOR DHCP

### 4.12.1 R1

```
bogota>ENA
bogota#CONF TERM
Enter configuration commands, one per line. End with CNTL/Z.
bogota(config)#interface fastEthernet 0/0.30
bogota(config-subif)#encapsulation dot1Q 30
bogota(config-subif)#ip address 192.168.30.1 255.255.255.0
bogota(config-subif)#exit
bogota(config)#interface fastEthernet 0/0.40
bogota(config-subif)#encapsulation dot1Q 40
bogota(config-subif)#ip address 192.168.40.1 255.255.255.0
bogota(config-subif)#exit
bogota(config)#ip dhcp pool Administracion
bogota(dhcp-config)#network 192.168.30.0 255.255.255.0
bogota(dhcp-config)#default-router 192.168.30.1
bogota(dhcp-config)#exit
bogota(config)#ip dhcp pool Mercadeo
bogota(dhcp-config)#network 192.168.40.0 255.255.255.0
bogota(dhcp-config)#default-router 192.168.40.1
bogota(dhcp-config)#exit
bogota(config)#exit
bogota#
%SYS-5-CONFIG_I: Configured from console by console
```

## 4.13 RESERVA DE DIRECCIONES IP

```
bogota#CONF TER
Enter configuration commands, one per line. End with CNTL/Z.
bogota(config)#ip dhcp excluded-address 192.168.30.1 192.168.30.30
bogota(config)##ip dhcp excluded-address 192.168.40.1 192.168.40.30
^
% Invalid input detected at '^' marker.
bogota(config)#ip dhcp excluded-address 192.168.40.1 192.168.40.30
bogota(config)#ip dhcp pool Administracion
bogota(dhcp-config)#dns-server 10.10.10.11
bogota(dhcp-config)#default-router 192.168.30.1
bogota(dhcp-config)#ip domain-name ccna-unad.com
bogota(config)#exit
```

```
bogota#  
%SYS-5-CONFIG_I: Configured from console by console  
  
bogota#ip dhcp pool Mercadeo  
^  
% Invalid input detected at '^' marker.  
bogota#CONF TERM  
Enter configuration commands, one per line. End with CNTL/Z.  
bogota(config)#ip dhcp pool Mercadeo  
bogota(dhcp-config)#dns-server 10.10.10.11  
bogota(dhcp-config)#default-router 192.168.40.1  
bogota(dhcp-config)#ip domain-name ccna-unad.com  
bogota(config)#exit  
bogota#  
%SYS-5-CONFIG_I: Configured from console by console
```

#### 4.14 CONFIGURACION DE NAT

```
miami>ENA  
miami#CONF TERM  
Enter configuration commands, one per line. End with CNTL/Z.  
miami(config)#ip nat inside source static 10.10.10.10 209.165.200.229  
miami(config)#interface gigabitEthernet 0/0  
%Invalid interface type and number  
miami(config)#interface FASTEthernet 0/0  
miami(config-if)#ip nat outside  
miami(config-if)#exit  
miami(config)#interface gigabitEthernet 0/1  
%Invalid interface type and number  
miami(config)#interface FASTEthernet 0/1  
miami(config-if)#ip nat outside  
miami(config-if)#exit  
miami(config)#exit  
miami#  
%SYS-5-CONFIG_I: Configured from console by console
```




Ilustración 39 Configuración NAT en R1

The screenshot shows a Windows-style application window titled "S1". The window has two tabs at the top: "Physical" (which is selected) and "CLI". Below the tabs is the title "IOS Command Line Interface". The main area of the window contains the following text:

```
Press RETURN to get started.

S1>enable
S1#ping 192.168.99.3/24
Translating "192.168.99.3/24"
% Unrecognized host or address or protocol not running.

S1#ping 192.168.99.3

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.99.3, timeout is 2
seconds:
.....
Success rate is 0 percent (0/5)

S1#
```

At the bottom right of the main window, there are two buttons: "Copy" and "Paste".

Ilustración 40 Configuración NAT en S1

## **5 CONCLUSIONES**

- Se genero seguridad en los diferentes dispositivos de la topología solicitada
- Se dio solución a los ejercicios usando los métodos de tecnologías CCNA
- Se propuso los diferentes enrutamientos según los temas estudiados en el curso.
- Se usaron los protocolos RIP como enrutamiento
- Se utilizo el encapsulamiento PPP y su debida autenticación
- Se diseño el enrutamiento dinámico según protocolos OSPF y DHCP
- Se realizaron las configuraciones de los dispositivos usado
- Se usaron los aspectos sobre la arquitectura TCP/IP
- Se realizó la configuración NAT para salida a internet
- Se ejecuto los diferentes comandos y protocolos para resolver las configuraciones y problemas establecidos
- Se verificaron procesos de comunicación y redireccionamiento de tráfico

## REFERENCIAS BIBLIOGRAFÍCAS

Fundamentos de Networking.

CISCO. (2014). Recuperado de <https://static-course-assets.s3.amazonaws.com/ITN50ES/module1/index.html#1.0.1.1>

Fundamentos de Networking

CISCO. (2014).. Recuperado de <https://static-course-assets.s3.amazonaws.com/ITN50ES/module2/index.html#6.0.1.1>

Asignación de direcciones IP.

Fundamentos de Networking.

CISCO. (2014). Recuperado de <https://static-course-assets.s3.amazonaws.com/ITN50ES/module8/index.html#8.0.1.1>

Soluciones de Red.

Fundamentos de Networking

CISCO. (2014).. Recuperado de <https://static-course-assets.s3.amazonaws.com/ITN50ES/module11/index.html#11.0.1.1>

Configuración y conceptos básicos de Switching.

Principios de Enrutamiento y Comutación.

CISCO. (2014). Recuperado de <https://static-course-assets.s3.amazonaws.com/RSE50ES/module2/index.html#2.0.1.1>

Enrutamiento entre VLANs.

Principios de Enrutamiento y Comutación.

CISCO. (2014). Recuperado de <https://static-course-assets.s3.amazonaws.com/RSE50ES/module5/index.html#5.0.1.1>

OSPF de una sola área.

Principios de Enrutamiento y Comutación. CISCO. (2014). Recuperado de <https://static-course-assets.s3.amazonaws.com/RSE50ES/module8/index.html#8.0.1.1>

Traducción de direcciones IP para IPv4.

Principios de Enrutamiento y Comutación. CISCO. (2014).

Recuperado de <https://static-course-assets.s3.amazonaws.com/RSE50ES/module11/index.html#11.0.1.1>

OSPF de una sola área.

Principios de Enrutamiento y Comunicación.

CISCO. (2014). Recuperado de <https://static-course-assets.s3.amazonaws.com/RSE50ES/module8/index.html#8.0.1.1>